


**LUGGAGE COMPARTMENT DOOR OPENER SWITCH CIRCUIT****CIRCUIT DESCRIPTION**

This circuit detects the state of the luggage door opener switch.

**WIRING DIAGRAM**

## INSPECTION PROCEDURE

### 1 READ VALUE OF INTELLIGENT TESTER II (LUGGAGE COMPARTMENT DOOR OPENER SWITCH)

- (a) Check the DATA LIST for proper functioning of the luggage compartment door opener switch.  
Driver Side J/B ECU:

Item	Measurement Item Display (Range)	Normal Condition	Diagnostic Note
Trnk/Bdr/Dn\$W	Trunk and Back door opener switch ON or OFF	ON: Luggage compartment door opener switch is pulled OFF: Luggage compartment door opener switch is not pulled	-


OK: "ON" (luggage compartment door opener switch is pulled) appears on the screen.

NG → Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2782)

### 2 INSPECT LUGGAGE OPENER SWITCH



- (a) Measure the resistance between the terminals of the connector when the switch is operated.

**Standard:**

Tester Connection	Switch Condition	Specified Condition
C-1 – D-2	ON	Below 1 $\Omega$
C-1 – D-2	OFF	10 k $\Omega$ or higher


NG → REPLACE THE LUGGAGE OPENER SWITCH

OK

3. CHECK WIRE HARNESS (LUGGAGE COMPARTMENT DOOR OPENER SWITCH - DRIVER SIDE J/B ECU AND BODY GROUND)

Wire Harness Side


L1  
Luggage Compartment  
Door Opener Switch



\*1: LHD

\*2: RHD

D5  
Driver Side J/B ECU



TSW\*1

TSW\*2

- (a) Disconnect the L1 switch connector.
- (b) Disconnect the D5 ECU connector.
- (c) Measure the resistance of the wire harness side connectors.

Tester Connection	Specified Condition
L1-1 - D5-5*1/6*2 (TSW)	Below 1 Ω
L1-2 - Body ground	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2782)