


INSPECTION

1. INSPECT REAR SUNSHADE SWITCH (in Rear seat control)

Switch position	Tester connection	Specified condition
OFF	–	No continuity
ON	1 – 2	Continuity


If continuity is not as specified, replace the switch.



2. INSPECT REAR SUNSHADE SWITCH

Switch position	Tester connection	Specified condition
OFF	–	No continuity
ON	6 – 7	Continuity

If continuity is not as specified, replace the switch.




3. Disconnect connector:

INSPECT REAR SUNSHADE CONTROL RELAY

Disconnect the connector from the rear sunshade relay and inspect the connector on the wire harness side, as shown.

Tester connection	Condition	Specified condition
3 – Ground	Rear sunshade switch OFF	No continuity
3 – Ground	Rear sunshade switch ON	Continuity
5 – Ground	Constant	Continuity
1 – Ground	Ignition switch OFF or ACC	No voltage
1 – Ground	Ignition switch ON	Battery positive voltage

If continuity is not as specified, replace the rear sunshade relay.




4. **Connect connector:**
INSPECT REAR SUNSHADE CONTROL RELAY

Connect the connector from the rear sunshade relay and inspect the connector on the wire harness side, as shown.

Tester connection	Condition	Specified condition
2 – Ground	Ignition switch ON and shift lever P position	No voltage
2 – Ground	Ignition switch ON and shift lever R position	Battery positive voltage
4 – Ground	Ignition switch ON and rear sunshade switch (rear seat control switch) ON	No voltage
4 – Ground	Ignition switch ON and rear sunshade switch (rear seat control switch) OFF	Battery positive voltage


If continuity is not as specified, replace the rear sunshade control relay.



5. **INSPECT REAR SUNSHADE MOTOR**

- (a) Connect the positive (+) lead from the battery to terminal 4 and the negative (–) lead to terminal 3, and check that the motor turns counterclockwise.
- (b) Reverse the polarity, check that the motor turns clockwise.

If operation is not as specified, replace the rear sunshade assembly.



6. **INSPECT SUB WIRE HARNESS (in Rear armrest)**

Tester connection	specified condition
A1 – B16	Continuity
A2 – B7	Continuity