

DTC	P0607	INPUT SIGNAL CIRCUIT MALFUNCTION
------------	--------------	---

CIRCUIT DESCRIPTION

This DTC indicates the internal abnormalities of the ECM.

DTC No.	Detection Item	Trouble Area
P0607	<p>The ECM has a supervisory CPU and a control ECU inside.</p> <p>When each input STP signal is different for 0.15 sec. or more, this trouble code is output.</p> <p>This trouble code is output after 0.4 sec. has passed from the time the cruise cancel input signal (STP input) is input into the ECM.</p>	<ul style="list-style-type: none"> • ECM

HINT:

The ECM receives signals from each sensor to control all the functions of the cruise control with the micro-computer.

When a trouble code is detected, fail-safe remains on until the ignition switch is turned off.

INSPECTION PROCEDURE

1	REPLACE ECM (SEE PAGE 10-21)
---	------------------------------