

FUEL PUMP CONTROL CIRCUIT

CIRCUIT DESCRIPTION

Refer to DTC P0230 on [page 05-122](#).

WIRING DIAGRAM

Refer to DTC P0230 on [page 05-122](#).

INSPECTION PROCEDURE

1 PERFORM ACTIVE TEST (OPERATE F/PMP RELAY)


- Connect the Intelligent Tester II to the DLC3.
- Turn the ignition switch ON and push the Intelligent Tester II main switch ON.
- Enter the following menus: Enter/Diagnosis/OBD-MOBD/Powertrain/Engine and ECT/Active Test/"Control the fuel pump/speed".
- Check the relay operation while operating it with the Intelligent Tester II.

OK: Operating noise can be heard from the relay.

OK → **Go to step 5**

NG

2 INSPECT RELAY (F/PMP)



- Remove the F/PMP relay from the engine room Relay Block (R/B).
- Measure the resistance.


Standard:

Tester Connection	Specified Condition
3 - 4	Below 1 Ω
3 - 4	10 kΩ or higher (apply battery voltage to terminals 1 and 2)

NG → **REPLACE RELAY (F/PMP)**

OK

3 INSPECT ECM (FC VOLTAGE)



- Turn the ignition switch ON.
- Measure the voltage of ECM connector.




Standard:

Tester Connection	Specified condition
E4-14 (FC) - Body ground	9 to 14 V

OK → **REPLACE ECM (See page 10-21)**

OK

4 CHECK WIRE HARNESS (ECM - C/OPN RELAY, C/OPN RELAY - IGNITION SWITCH)



(a) Check the wire harness between the ECM and the C/OPN relay.

- (1) Disconnect the E4 ECM connector.
- (2) Remove the C/OPN relay from the engine room R/B.
- (3) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
E4-14 (FC) - R/B C/OPN relay terminal 2	Below 1 Ω
E4-14 (FC) or 2 of C/OPN relay - Body ground	10 k Ω or higher

(b) Check the wire harness between the C/OPN relay and the ignition switch.

- (1) Check the IG2 fuse.
 - Remove the IG2 fuse from the engine room R/B.
 - Measure the resistance of the IG2 fuse.

Standard: Below 1 Ω

- Reinstall the IG2 fuse.
- (2) Remove the C/OPN relay from the engine room R/B.
- (3) Disconnect the I17 ignition switch connector.
- (4) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
R/B C/OPN relay terminal 1 - I17-6	Below 1 Ω
R/B C/OPN relay terminal 1 or I17-6 - Body ground	10 k Ω or higher


NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

REPLACE ECM (See page 10-21)

5 INSPECT FUEL PUMP



Fuel Pump

A74356

- (a) Check the fuel pump resistance.
- (1) Measure the resistance between terminals 4 and 5.
Standard: 0.2 to 3.0 Ω at 20°C (68°F)
- (b) Check the fuel pump operation
- (1) Apply battery voltage to both the terminals. Check that the pump operates.

NOTICE:

- These tests must be done quickly (within 10 seconds) to prevent the coil from burning out.
- Keep fuel pump as far away from the battery as possible.

CAUTION:

Always turn on and off the voltage on the battery side, not the fuel pump side.


NG

REPLACE FUEL PUMP (See page 11-21)

OK


6 CHECK WIRE HARNESS (C/OPN RELAY - FUEL PUMP - BODY GROUND)

Engine Room R/B



A87993

Wire Harness Side

F19
Fuel Pump

P

A67586

- (a) Check the wire harness between the C/OPN relay and the fuel pump.
- (1) Remove the C/OPN relay from the engine room R/B.
- (2) Disconnect the F19 fuel pump connector.
- (3) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
R/B C/OPN relay terminal 3 - F19-4 (Fuel pump)	Below 1 Ω
R/B C/OPN relay terminal 3 or F19-4 (Fuel pump) - Body ground	10 k Ω or higher

- (4) Measure the resistance of the wire harness side connector.

Standard:

Tester Connection	Specified Condition
F19-5 - Body ground	Below 1 Ω

NG

REPLACE ECM (See page 10-21)

OK

REPAIR OR REPLACE HARNESS AND CONNECTOR