

**PASSENGER DOOR ECU POWER SOURCE CIRCUIT**

**CIRCUIT DESCRIPTION**

This circuit supplies power to operate the passenger door ECU.

**Passenger Side J/B**

**Driver Side J/B**

**FL Block Assy**

**Front Passenger Door ECU**

**Battery**

**Legend:**  
 \*1: LHD  
 \*2: RHD

INSPECTION PROCEDURE


1 INSPECT FUSE (MPX-IG, AM1, P DOOR, MPX-B1, D/C CUT)

- (a) Remove the MPX-IG and AM1 fuses from the driver side J/B.
  - (b) Remove the P DOOR and MPX-B1 fuses from the passenger side J/B.
  - (c) Remove the D/C CUT fuse from the FL block.
  - (d) Measure the resistance.
- Standard: Below 1 Ω

NG REPLACE FUSE

OK

2 INSPECT RELAY (D-IG1)




- (a) Remove the D-IG1 relay from the driver side J/B.
  - (b) Check the resistance.
- Standard:

Tester Connection	Specified Condition
3 - 5	10kΩ or higher
3 - 5	Below 1 Ω (when battery voltage is applied to terminals 1 and 2)

NG REPLACE RELAY

OK

3 CHECK WIRE HARNESS (FRONT PASSENGER DOOR ECU - BODY GROUND)



- (a) Disconnect the F17 ECU connector.
  - (b) Measure the voltage and resistance of the wire harness side connector and the body ground.
- Standard:

Tester Connection	Condition	Specified Condition
F17-4 (CPUB) - Body Ground	Constant	10 to 14 V
F17-6 (BDR) - Body Ground	Constant	10 to 14 V
F17-5 (SIG) - Body Ground	Ignition switch OFF → ON	0 V → 10 to 14 V
F17-1 (GND) - Body Ground	Constant	Below 1 Ω

NG REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE  
(See page 05-2080)