

# REAR POWER SEAT CONTROL SYSTEM

05CUS-04

## PRECAUTION

### NOTICE:

When disconnecting the negative (-) battery terminal, initialize the following systems after the terminal is reconnected.

| System Name                     | See Page                |
|---------------------------------|-------------------------|
| Power Window Control System     | <a href="#">05-1984</a> |
| Front Power Seat Control System | <a href="#">05-2280</a> |
| Back Guide Monitor System       | <a href="#">05-1913</a> |