

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Driver seat belt warning lamp does not flash	1. Buckle switch circuit (driver side) 2. Bulb circuit (driver side) 3. ECU power source circuit If the 3 suspected areas above are functioning normally, replace the driver side J/B ECU.	05-1337 05-2151 05-1334
Passenger seat belt warning lamp does not flash	1. Buckle switch circuit (passenger side) 2. Bulb circuit (passenger side)	05-1331 05-2151
Seat belt warning buzzer does not sound*	1. Buzzer circuit 2. Buckle switch circuit (driver side) If the 2 suspected areas above are functioning normally, replace the driver side J/B ECU.	05-2151 05-1337

HINT:

*: G.C.C. Countries