

TIRE PRESSURE WARNING SYSTEM

05HNU-01

PRECAUTION

NOTICE:

When disconnecting the negative (–) battery terminal, initialize the following systems after the terminal is reconnected.

System Name	See Page
Power window Control System	01-20
Front Power Seat Control System	01-20
Back Guide Monitor System	01-20

1. TIRE PRESSURE WARNING SYSTEM PRECAUTION

- (a) This system requires initializing after changing tires or wheels, or after rotating the tires (see page 28-1).