

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below. Then proceed to the page given for that circuit.

DTC No. (See Page)	Detection Item	Trouble Area
B1222 (05-2545)	Door Lock Switch Circuit on Driver Door	<ul style="list-style-type: none"><li>• Door lock switch</li><li>• Door key lock and unlock switch</li><li>• Wire harness</li><li>• Driver door ECU</li></ul>
B1224 (05-2549)	Door Lock Switch Circuit on Passenger Door	<ul style="list-style-type: none"><li>• Door lock switch</li><li>• Wire harness</li><li>• Passenger door ECU</li></ul>