



INSPECTION

INSPECT FOG LIGHT CONTROL RELAY CONTINUITY

| Condition                           | Tester connection | Specified condition |
|-------------------------------------|-------------------|---------------------|
| Constant                            | 1 - 2             | Continuity          |
| Apply B+ between terminals 1 and 2. | 3 - 4             | Continuity          |

If continuity is not as specified, replace the relay.