


# LUGGAGE COMPARTMENT DOOR COURTESY SWITCH CIRCUIT

## CIRCUIT DESCRIPTION

The door courtesy lamp turns on when the door is open and turns off when the door is closed.

The luggage room J/B ECU detects the condition of the door courtesy switch and sends the information to each ECU via the multiplex communication circuit.

## WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER II (DOOR COURTESY SWITCH)

- (a) Check the DATA LIST for proper functioning of the door courtesy switch.  
Luggage Room J/B ECU:

Item	Measurement Item/Display (Range)	Normal Condition	Diagnostic Note
Lugg Courtsy	Door courtesy switch signal /ON or OFF	ON: Door is open OFF: Door is closed	-


OK: "ON" (door is open) appears on the screen.

NG Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOM TABLE  
(See page 05-2529)

2 INSPECT LUGGAGE COMPARTMENT DOOR LOCK ASSY (LUGGAGE COMPARTMENT DOOR COURTESY LAMP SWITCH ASSY)



- (a) Remove the luggage door lock.  
(b) Measure the resistance of the switch.

Standard:

Tester Connection	Switch Position	Specified Condition
3 - 4	Not Pushed (ON)	Below 1 Ω
3 - 4	Pushed (OFF)	10 kΩ or higher


NG REPLACE LUGGAGE COMPARTMENT DOOR LOCK ASSY

OK

3 CHECK WIRE HARNESS (LUGGAGE COMPARTMENT DOOR LOCK ASSY - LUGGAGE ROOM J/B)


Wire Harness Side

L4  
Luggage Compartment Door Closer Assy



T

L11  
Luggage Room J/B ECU



B69839  
B62731

B78606

- (a) Disconnect the L4 lock and L11 ECU connectors.
- (b) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
L4-4(CTY) - L11-4(LCTY)	Below 1 Ω
L5-3(E) - Body Ground	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOM TABLE  
(See page 05-2529)