

REMOVAL

1. REMOVE REAR LUGGAGE COMPARTMENT TRIM SIDE COVER, FRONT LUGGAGE TRIM COVER AND REAR FLOOR FINISH PANEL (See page BO-58)
2. DISCONNECT CONNECTOR
3. REMOVE REAR ACCELERATION SENSOR

Remove the bolt and rear acceleration sensor.