


ECU POWER SOURCE CIRCUIT

CIRCUIT DESCRIPTION

This circuit provides power to operate the driver side J/B ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT FUSE (AM1, MPX-IG, MPX-B3)


- (a) Remove the AM1 fuse and MPX-IG fuse from the driver side J/B.
 (b) Remove the MPX-B3 fuse from the passenger side J/B.
 (c) Measure the resistance.

Standard: Below 1 Ω

NG

REPLACE FUSE

OK

2 CHECK WIRE HARNESS (DRIVER SIDE J/B AND DRIVER SIDE J/B ECU - BODY GROUND)**Wire Harness Side**

- (a) Disconnect the DA, DE, DF, DG J/B and D4 ECU connectors.
 (b) Measure the voltage and resistance of the wire harness side connectors.

Standard:

LHD models

Tester Connection	Condition	Specified Condition
DA-1 (MPX-IG) - Body ground	Constant	10 to 14 V
D4-5 (MPX-B) - Body ground	Constant	10 to 14 V
DG-8 (GND) - Body ground	Constant	Below 1 Ω
D4-1 (GND2) - Body ground	Constant	Below 1 Ω
DE-17 (MPX-IG) -DF-4 (GND)	Ignition switch OFF \rightarrow ON	10 k Ω or higher \rightarrow Below 1 Ω

RHD models


Tester Connection	Condition	Specified Condition
DA-1 (MPX-IG) - Body ground	Constant	10 to 14 V
D4-1 (MPX-B) - Body ground	Constant	10 to 14 V
DG-7 (GND) - Body ground	Constant	Below 1 Ω
D4-5 (GND2) - Body ground	Constant	Below 1 Ω
DE-13 (MPX-IG) -DF-6 (GND)	Ignition switch OFF \rightarrow ON	10 k Ω or higher \rightarrow Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

3 INSPECT RELAY (D-IG1)



- (a) Remove the D-IG1 relay from the driver side J/B.
- (b) Measure the resistance.

Standard:

Tester Connection	Specified Condition
3 - 5	10 kΩ or higher
3 - 5	Below 1 Ω (when battery voltage is applied to terminals 1 and 2)

NG ➡ REPLACE RELAY

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE
(See page 05-1329)