

ABS SYSTEM MALFUNCTION

CIRCUIT DESCRIPTION

The skid control ECU outputs DTC when a speed sensor malfunction occurs or there is an open in the stop lamp switch assy circuit of the ABS system.

INSPECTION PROCEDURE

1 CHECK DIAGNOSTIC CODE OUTPUT

(a) Check if the normal system code is output in the ABS system (see page 05-400).

OK:

DTC is not output.

NG

REPAIR CIRCUIT INDICATED BY OUTPUT CODE

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-352)