

<b>DTC</b>	<b>P0607</b>	<b>INPUT SIGNAL CIRCUIT MALFUNCTION</b>
------------	--------------	---

## CIRCUIT DESCRIPTION

This DTC indicates a malfunction in the ECM.

### HINT:

The ECM receives signals from each sensor to control all the functions of the cruise control.

When a malfunction is detected, fail-safe remains on until the ignition switch is turned OFF.

DTC No.	DTC Detection Condition	Trouble Area
P0607	(ECM has built-in supervisory CPU and control ECU) Each input STP signal is different for 0.15 sec. or more	ECM

### HINT:

This trouble code is output 0.4 seconds after the cruise cancel input signal (STP input) is input to the ECM.

## INSPECTION PROCEDURE

<b>REPLACE ECM (See Pub. No. RM1049E, page 10-21)</b>
---