


## DTC CHECK/CLEAR



### 1. CHECK DTC

DTCs which are stored in the ECM can be displayed with the Intelligent Tester and generic OBD scan tool.

These scan tools can display pending DTCs and current DTCs. Some DTCs aren't stored if the ECM doesn't detect a malfunction during consecutive driving. However, the detected malfunction during once driving is stored as pending DTC.

- Connect the Intelligent Tester to the Data Link Connector 3 (DLC3).
- Turn the ignition switch ON.
- Enter the following menus: Enter/Powertrain/Engine and ECT/DTC/Current (or Pending).
- Confirm the DTCs and freeze frame data and then write them down.
- See page 05-560 to confirm the details of the DTCs.

#### NOTICE:

**When simulating a symptom with the scan tool to check the DTCs, use normal mode. For codes on DIAGNOSTIC TROUBLE CODE CHART subject to "2-trip detection logic", perform the following actions.**

Turn the ignition switch OFF after the symptom is simulated once. Then repeat the simulation process again. When the problem has been simulated twice, the MIL illuminates and the DTCs are recorded in the ECM.

### 2. CLEAR DTC WITH INTELLIGENT TESTER

- Connect the Intelligent Tester to the DLC3.
- Turn the ignition switch ON.
- Enter the following menus: Enter/Powertrain/Engine and ECT/DTC/Clear.

### 3. CLEAR DTC WITHOUT INTELLIGENT TESTER

Disconnect the battery cable or remove the EFI MAIN fuse from the engine room R/B for 60 seconds or more.

#### NOTICE:

**When disconnecting the battery terminal, initialization is necessary (see page 01-20).**