

## ON-VEHICLE INSPECTION

### 1. CHECK KEY REMINDER WARNING SYSTEM

- (a) Check that the key reminder warning buzzer sounds.
  - (1) Close the driver side door, insert the key into the ignition key cylinder and then turn the key to the LOCK or ACC position.
  - (2) Open the driver side door and check that the buzzer sounds intermittently.
- (b) Check that the key reminder warning buzzer stops.
  - (1) Check that the buzzer stops sounding if any of the following operations is performed while the buzzer is sounding:
    - Close the driver side door (front door courtesy lamp switch is off).
    - Turn the ignition switch ON.
    - Pull out the key from the ignition key cylinder.