


## REMOVAL

1. **REMOVE FRONT WHEEL**  
Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)
2. **DISCONNECT TIE ROD END FROM LOWER BALL JOINT**

- (a) Remove the clip and nut from the tie rod end.

**Torque: 59 N·m (600 kgf·cm, 43 ft·lbf)**



- (b) Using SST, disconnect the tie rod end from the lower ball joint.

SST 09610-20012

3. **DISCONNECT LOWER BALL JOINT FROM STEERING KNUCKLE**


Remove the 2 bolts and disconnect the lower ball joint from the steering knuckle.

**Torque: 113 N·m (1,150 kgf·cm, 83 ft·lbf)**

4. **REMOVE LOWER BALL JOINT FROM LOWER SUSPENSION ARM**

- (a) Remove the clip and nut.

**Torque: 162 N·m (1,645 kgf·cm, 119 ft·lbf)**



- (b) Using SST, disconnect the lower ball joint from the lower suspension arm.

SST 09628-62011

- (c) Remove the lower ball joint from lower suspension arm.