

DATA LIST/ACTIVE TEST

1. DATA LIST

HINT:

By the DATA LIST displayed on the hand-held tester, you can read the value of the switch, sensor, actuator and so on without removing any parts. Reading the DATA LIST as the first step in troubleshooting is one of the methods to shorten labor time.

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch to the ON position.
- (c) According to the display on the tester, read the "DATA LIST".

SPAD:

Item	Measurement Item/ Display (Range)	Normal Condition	Diagnostic Note
Audio Mode SW	Audio mode switch/ ON or OFF	ON: Audio mode switch is pushed OFF: Audio mode switch is not pushed	–
Audio Volume UP SW	Audio volume UP switch/ ON or OFF	ON: Audio volume UP switch is pushed OFF: Audio volume UP switch is not pushed	–
Audio Volume Down SW	Audio volume DOWN switch/ ON or OFF	ON: Audio volume DOWN switch is pushed OFF: Audio volume DOWN switch is not pushed	–
Audio Selector UP SW	Audio selector UP switch/ ON or OFF	ON: Audio selector UP switch is pushed OFF: Audio selector UP switch is not pushed	–
Audio Selector Down SW	Audio selector DOWN switch/ ON or OFF	ON: Audio selector DOWN switch is pushed OFF: Audio selector DOWN switch is not pushed	–
Audio Volume Set SW	Audio volume set switch/ ON or OFF	ON: Audio volume set switch is pushed OFF: Audio volume set switch is not pushed	–
Spch Recognition Hook SW	Speech recognition hook switch/ ON or OFF	ON: Speech recognition hook switch is pushed OFF: Speech recognition hook switch is not pushed	–