



REMOVAL

1. REMOVE FRONT SEAT OUTER BELT ANCHOR

- (a) Using a screwdriver, remove the seat belt anchor cover cap.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the front seat outer belt anchor.

Torque: 42 N·m (430 kgf·cm, 31 ft·lbf)

2. REMOVE SEAT TRACK COVER

Using a screwdriver, pry out the 4 covers.

HINT:

Tape the screwdriver tip before use.

3. REMOVE FRONT SEAT

- (a) Remove the 4 bolts.

Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)

- (b) Disconnect the connectors.