

CUSTOMIZE PARAMETERS

HINT:

The followings items can be customized.

NOTICE:

- **When the customer requests a change in a function, first make sure that customization of the function(s) is possible.**
- **Be sure to record the current settings before customizing.**
- **When troubleshooting a function, first make sure that the function is not set to OFF.**

Sliding Roof:

Display (Item)	Default	Contents	Setting
OPEN/DOOR KEY (Door key related OPEN)	ON	Function to open sliding roof manually. Turn ignition switch OFF. Sliding roof links with power window after driver side door key is held to unlock side for 2 seconds or more.	ON/OFF
CLOSE/DOOR KEY (Door key related CLOSE)	ON	Function to close sliding roof manually. Turn ignition switch OFF. Sliding roof links with power window after driver side door key is held to lock side for 2 seconds or more.	ON/OFF
OPEN/WIRELESS (Wireless key related OPEN)	ON	Function to open sliding roof manually. Turn ignition switch OFF. Sliding roof links with power window after transmitter unlock button is pressed for 2 seconds.	ON/OFF
DOOR KEY OPER (Door key related operation)	SLIDE	Function to select manual opening direction. Turn ignition switch OFF. Sliding roof links with power window after key is inserted into driver side door key cylinder and key is held to unlock side for 2 seconds or more.	TILT/SLIDE
WIRELESS OPER (Wireless key related operation)	SLIDE	Function to select manual opening direction. Turn ignition switch OFF. Sliding roof links with power window after transmitter unlock button is pressed for 3 seconds or more.	TILT/SLIDE
CLOSE/WIRELESS (Wireless key related CLOSE)	ON	Function to select manual direction. Turn ignition switch OFF. Sliding roof links with power window after transmitter lock button is pressed for 3 seconds or more. (except Europe and Australia spec.)	ON/OFF