

# PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Driver side door closer system does not operate	1. Driver side J/B	<a href="#">05-2720</a>
	•MPX-B1 fuse	
	2. Passenger side J/B	<a href="#">05-2722</a>
	•MPX-IG, D DOOR fuse	
	3. Wire harness	–
	4. Door Lock assembly	<a href="#">05-2762</a>
	•Cam position switch	
	•Pole switch	
	•Half latch switch	
	•Full latch switch	
	•Lock position switch	
	•Closer motor	
	•Door lock motor	
	5. Driver door ECU	<a href="#">05-2720</a>
Passenger side door closer system does not operate	1. Driver side J/B	<a href="#">05-2720</a>
	•MPX-B1 fuse	
	2. Passenger side J/B	<a href="#">05-2722</a>
	•MPX-IG, P DOOR fuse	
	3. Wire harness	–
	4. Door Lock assembly	<a href="#">05-2762</a>
	•Cam position switch	
	•Pole switch	
	•Half latch switch	
	•Full latch switch	
	•Lock position switch	
	•Closer motor	
	•Door lock motor	
	5. Passenger door ECU	<a href="#">05-2722</a>
Rear left side door closer system does not operate	1. Driver side J/B	<a href="#">05-2720</a>
	•MPX-B1 fuse	
	2. Passenger side J/B	<a href="#">05-2722</a>
	•MPX-IG, RR DOOR LH fuse	
	3. Wire harness	–
	4. Door Lock assembly	<a href="#">05-2762</a>
	•Cam position switch	
	•Pole switch	
	•Half latch switch	
	•Full latch switch	
	•Lock position switch	
	•Closer motor	
	•Door lock motor	
	5. Rear left door ECU	<a href="#">05-2725</a>
Rear right side door closer system does not operate	1. Driver side J/B	<a href="#">05-2720</a>
	•MPX-B1 fuse	
	2. Passenger side J/B	<a href="#">05-2722</a>
	•MPX-IG, RR DOOR LH fuse	
	3. Wire harness	–
	4. Door Lock assembly	<a href="#">05-2762</a>
	•Cam position switch	
	•Pole switch	
	•Half latch switch	
	•Full latch switch	
	•Lock position switch	
	•Closer motor	
	•Door lock motor	
	5. Rear left door ECU	<a href="#">05-2729</a>