

DATA LIST/ACTIVE TEST

1. ACTIVE TEST

HINT:

Performing the intelligent tester II ACTIVE TEST allows relay, VSV, actuator and other items to be operated without removing any parts. Performing the ACTIVE TEST early in troubleshooting is one way to shorten labor time.

- (a) Connect the intelligent tester II to the DLC3.
- (b) Turn the ignition switch ON.
- (c) Perform the ACTIVE TEST according to the display on the tester.

A/C control assembly:

Item	Test Details	Diagnostic Note
Defogger Rly-R	Operate rear window defogger OFF/ON	-