


INSTALLATION

1. INSTALL ELECTRIC COOLING FAN TO RADIATOR

- (a) Install the electric cooling fan with the 6 bolts.
Torque: 5.0 N·m (50 kgf·cm, 44 in·lbf)
- (b) Unpressurized Reservoir Tank System:
Connect the radiator reservoir hose to the radiator.



2. INSTALL RADIATOR AND ELECTRIC COOLING FAN ASSEMBLY

- (a) Install the 2 lower radiator supports to the radiator.
- (b) Attach the 2 lower radiator supports on the radiator to the body bracket.
- (c) Install the radiator and electric cooling fan assembly with the 2 upper radiator supports and 2 nuts.
Torque: 13.5 N·m (135 kgf·cm, 10 ft·lbf)
- (d) Connect the upper radiator hose to radiator.
- (e) Connect the lower radiator hose to radiator.
- (f) Connect the ECM outlet duct to ECM box.
- (g) Connect the 2 oil cooler hoses for A/T to radiator.
- (h) Connect the cooling fan computer connector.
- (i) Pressurized Reservoir Tank System:
Connect the radiator reservoir hose to the radiator.

3. INSTALL AIR CLEANER ASSEMBLY

4. INSTALL AIR CLEANER INLET

5. FILL WITH ENGINE COOLANT (See page CO-2)

6. START ENGINE AND CHECK FOR ENGINE COOLANT AND A/T FLUID LEAKS

7. INSTALL ENGINE UNDER COVER