

INSTALLATION

Installation is to be done in the reverse order of removal (See page BR-63).

HINT:

After installation, check speed sensor signal (See page DI-343).