


REMOVAL

1. REMOVE REAR WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)




2. REMOVE NO. 1 LOWER SUSPENSION ARM

- (a) Remove the nut and bolt on body side of No. 1 lower suspension arm.


Torque: 90 N·m (910 kgf·cm, 66 ft·lbf)

- (b) Remove the nut on axle carrier side of No. 1 lower suspension arm.

Torque: 70 N·m (720 kgf·cm, 52 ft·lbf)



- (c) Using SST, remove the No. 1 lower suspension arm.
SST 09628-00011 (09628-00030, 09628-00040, 09628-00050)




3. REMOVE NO. 2 LOWER SUSPENSION ARM

- (a) Place matchmarks on the link and bracket, remove the nut and disconnect the height control sensor link from the No. 2 lower suspension arm.

Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)

- (b) Remove the nut and disconnect the stabilizer bar link.

Torque: 65 N·m (660 kgf·cm, 48 ft·lbf)




- (c) Remove the nut and bolt on body side of No. 2 lower suspension arm.

Torque: 90 N·m (910 kgf·cm, 66 ft·lbf)

- (d) Remove the nut on axle carrier side of No. 2 lower suspension arm.

Torque: 70 N·m (720 kgf·cm, 52 ft·lbf)



- (e) Using SST, remove the No. 2 lower suspension arm.
SST 09628-00011 (09628-00030, 09628-00040, 09628-00050)