



# COMBINATION METER

## PRECAUTION

05HR0-01

### REMOVAL AND INSTALLATION OF BATTERY TERMINAL

- (a) Before performing electronic work, disconnect the battery negative (-) terminal cable in order to prevent it from shorting and burning out.
- (b) When disconnecting and reconnecting the battery cable, turn the ignition switch and lighting switch off and loosen the terminal nut completely. Perform operations without twisting or prying on the terminal.
- (c) When the battery terminal cable is removed, the memories of the clock, radio, DTCs, etc. are erased. So before removing it, check and make a note of them.

### NOTICE:

When disconnecting the battery negative (-) terminal, initialize the following systems after the terminal is reconnected.

System Name	See Page
Power Window Control System	01-20
Back Guide Monitor System	01-20
Front Power Seat Control System	01-20