


## VIBRATOR CIRCUIT (LH)

### CIRCUIT DESCRIPTION


The rear LH seat ECU sends a vibration seat function signal to the vibrator through the vibration seat ECU.

### WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT VIBRATOR LH



- (a) Remove the vibrator LH.
- (b) Measure the resistance of the vibrator.

Standard:

Tester Connection	Specified Condition
1*1 – 2	1.8 ± 0.3 Ω
1 and 2*2 – Body ground	5 MΩ or more at DC 500 VM
3 – Body ground	0 Ω

HINT:


- \*1: Connect terminal 1 to the tester's positive (+) terminal.
- \*2: Terminals 1 and 2 should be connected together

NG

REPLACE VIBRATOR LH

OK

2 CHECK WIRE HARNESS (VIBRATION SEAT ECU LH – VIBRATOR LH)



- (a) Disconnect the V10 ECU and V12 vibrator connectors.
- (b) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
V10-12 (VIBE) – V12-3 (C3)	Below 1 Ω
V10-1 (VIB+) – V12-1 (C2)	Below 1 Ω
V10-6 (VIB-) – V12-2 (C1)	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE  
(See [page 05-2340](#))