

<b>DTC</b>	<b>P0500</b>	<b>VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION</b>
------------	--------------	---

<b>DTC</b>	<b>P0503</b>	<b>VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION</b>
------------	--------------	---

## CIRCUIT DESCRIPTION

See Pub. No. RM1049E, page 05-172.

DTC No.	DTC Detection Condition	Trouble Area
P0500	Vehicle speed signal from vehicle speed sensor is cut for 0.14 sec. or more while cruise control is in operation	<ul style="list-style-type: none"> <li>• Combination meter assy</li> <li>• Vehicle speed sensor</li> <li>• Vehicle speed sensor signal circuit</li> <li>• ECM</li> </ul>
P0503	Momentary interruption and noise are detected when rapid change of vehicle speed occurs while cruise control is in operation	<ul style="list-style-type: none"> <li>• Combination meter assy</li> <li>• Vehicle speed sensor</li> <li>• Vehicle speed sensor signal circuit</li> <li>• ECM</li> </ul>

## WIRING DIAGRAM

See Pub. No. RM1049E, page 05-172.

## INSPECTION PROCEDURE

See Pub. No. RM1049E, page 05-172.