



DISASSEMBLY

REMOVE SUSPENSION SUPPORT AND COIL SPRING

- (a) Using SST, compress the coil spring until there is a clearance on both ends.

SST 09727-30021

NOTICE:

Do not use an impact wrench. It will damage the SST.

- (b) Remove the suspension support nut and rebound stopper.
- (c) Remove the suspension support, insulator and coil spring.