

## ON-VEHICLE INSPECTION

### 1. CHECK LUGGAGE COMPARTMENT CLOSER SYSTEM

- (a) Make the luggage door ajar (luggage courtesy switch OFF and door open/close detection switch OFF). Check that the motor starts operating and fully closes (fully locks) the door.
- (b) Make the luggage door ajar (luggage courtesy switch OFF and door open/close detection switch OFF). When the motor starts operating, perform luggage door opening operation by turning on any of the following switches: 1) the door unlock switch (key switch); 2) the luggage electrical key switch\*; or 3) the trunk panel (luggage compartment door) opening switch. Check that the motor stops its operation and starts reverse rotations (starts opening). As a result, the luggage door should not be in the fully closed position.

\*: w/ Smart key system

### 2. CHECK LUGGAGE COMPARTMENT OPENER SYSTEM

- (a) Pull the trunk panel (luggage compartment door) opening switch. Check that the luggage compartment door is opened.
- (b) Insert the key into the key cylinder on the opening switch and push the key to the LOCK position. Check that pulling the trunk panel (luggage compartment door) opening switch does not open the luggage compartment door.