

DTC	U0001	HIGH SPEED CAN COMMUNICATION CIRCUIT
------------	--------------	---

CIRCUIT DESCRIPTION

The engine control unit and the transmission control unit are located inside the ECM. The engine control unit intercommunicates with the transmission control ECU with the Controller Area Network (CAN).

If there is a problem in this intercommunication, the ECM sets a DTC.

DTC No.	DTC Detection Condition	Trouble Area
U0001	The following conditions are met for 2 seconds (1 trip detection logic): (a) Ignition switch ON (b) Battery voltage is 10 V or more (c) No intercommunication between engine control ECU and transmission control ECU	ECM

INSPECTION PROCEDURE

REPLACE ECM (See page 10-21)