

# ELECTRONIC CONTROLLED AUTOMATIC TRANSMISSION [ECT]

05HMH-01

## PRECAUTION

### NOTICE:

When the negative (-) battery terminal is disconnected, initialize the following systems after the terminal is reconnected.

System Name	See page
Power Window Control System	01-20
Front Power Seat Control System	01-20
Back Guide Monitor System	01-20

### NOTICE:

Perform the RESET MEMORY (AT initialization) when replacing the automatic transmission assy, engine assy or ECM (see page 05-535).

### HINT:

Initialization can not be completed by only disconnecting the battery terminal.