


## WASHER MOTOR CIRCUIT

### CIRCUIT DESCRIPTION

The front light ECU receives washer switch information from the combination switch, and operates the washer relay.

### WIRING DIAGRAM



# INSPECTION PROCEDURE

## 1 PERFORM ACTIVE TEST ON INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch to the ON position and turn the intelligent tester main switch on.
- (c) Select the item below in the ACTIVE TEST and then check that the washer motor operates.

**BODY NO.5 (MULTIPLEX NETWORK FRONT LIGHT ECU):**

Item	Test Details	Diagnostic Note
Washer Motor Operation	Washer Motor OFF/ON	-


**OK:** Washer motor operates.

**NG** Go to step 2


**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1582)**

## 2 INSPECT RELAY



- (a) Remove the WSH relay from the engine room No.2 relay block.



- (b) Measure the resistance according to the value(s) in the table below.

**Standard:**


Tester connection	Specified condition
3 - 5	10 kΩ or higher
3 - 5	Below 1 Ω (When battery voltage is applied to terminals 1 - 2)

**NG** REPLACE RELAY

**OK**

3

INSPECT MULTIPLEX NETWORK BODY ECU(ENGINE ROOM NO.2 R/B)



- (a) Using a service wire, connect R13 and R14 in the engine room No.2 relay block.


**OK: Front window washer operates.**

OK

NG Go to step 5

4 INSPECT MULTIPLEX NETWORK BODY ECU (ENGINE ROOM NO.2 R/B)

Engine Room No.2 R/B  
Connector Front View:




N

I37540

- (a) Disconnect the 2-11 connector from the engine room No.2 relay block.
- (b) Remove the front light ECU from the engine room No.2 relay block.

Engine Room No.2 R/B  
Relay Side View:



N

I37539

- (c) Using a service wire, connect R15 and R16 in the engine room No.2 relay block.
- (d) Measure the resistance according to the value(s) in the table below.

Standard:


Tester connection	Condition	Specified condition
2-11 -E5	Connect R15 and R16	Below 1 Ω

NG

REPLACE MULTIPLEX NETWORK BODY ECU (ENGINE ROOM NO.2 R/B)

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE  
(SEE PAGE 05-1582)

**5 CHECK HARNESS AND CONNECTOR(POWER SOURCE CIRCUIT)****Engine Room No.2 R/B  
Connector Front View:**

- (a) Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
2-11 (FWAS) – Body ground	Always	10 to 14 V


**NG****REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****6 INSPECT MULTIPLEX NETWORK BODY ECU(ENGINE ROOM NO.2 R/B)****Engine Room No.2 R/B  
Connector Front View:**

- (a) Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
2-10 (W+) – Body ground	Connect R13 and R14	10 to 14 V

**NG****Go to step 8****OK**

**7 INSPECT WINDSHIELD WASHER MOTOR AND PUMP ASSY**

- (a) Disconnect the windshield washer motor and pump assy connector.
- (b) Connect the positive battery (+) lead to terminal 2 of the windshield washer motor and pump assy, and the negative battery (-) lead to terminal 1.

**OK: Operation sounds are heard.**

**NG**


**REPLACE WINDSHIELD WASHER MOTOR AND PUMP ASSY**

**OK**

**REPAIR OR REPLACE HARNESS OR CONNECTOR(WASHER MOTOR CIRCUIT)**

8 INSPECT MULTIPLEX NETWORK BODY ECU (ENGINE ROOM NO.2 R/B)


Engine Room No.2 R/B  
Connector Front View:



N I37540

- (a) Disconnect the 2-11 connector from the engine room No.2 relay block.
- (b) Remove the front light ECU from the engine room No.2 relay block.

Engine Room No.2 R/B  
Relay Side View:



N I37539

- (c) Using a service wire, connect R15 and R16 in the engine room junction block.
- (d) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
2-1 - 2-11	Connect R13 and R14	Below 1 Ω
2-11 - E5	Connect R15 and R16	Below 1 Ω

NG

REPLACE MULTIPLEX NETWORK BODY ECU (ENGINE ROOM NO.2 R/B)

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE  
(SEE PAGE 05-1582)