


## HEADLIGHT SIGNAL CIRCUIT

### CIRCUIT DESCRIPTION

The driver side J/B ECU receives the HEAD position signal of light control switch to operate the HEAD relay. The HEAD position signal is also transmitted to the driver side J/B ECU by the multiplex network communication system and the back-up communication bus.

### WIRING DIAGRAM




INSPECTION PROCEDURE

1 CHECK HARNESS AND CONNECTOR (HEADLIGHT SIGNAL CIRCUIT)

- (a) Disconnect the D4 connector from the driver side junction block.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
D4-8 - Body ground	Light control switch in HEAD position	Below 1 Ω
D4-8 - Body ground	Light control switch in except HEAD position	10 kΩ or higher



HINT:


This illustration is for RHD model. The RHD and LHD models are symmetrical.

NG Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE  
(SEE PAGE 05-1369)

2 INSPECT TURN SIGNAL SWITCH ASSY (COMBINATION SWITCH)



(a) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
C14-4 - C14-8	Light control switch in HEAD position	Below 1 Ω
C14-4 - C14-8	Light control switch in except HEAD position	10 kΩ or higher

NG REPLACE TURN SIGNAL SWITCH ASSY (SEE PAGE 65-25)

OK

REPAIR OR REPLACE HARNESS OR CONNECTOR (COMBINATION SWITCH - DRIVER SIDE JUNCTION BLOCK ASSY)