


TERMINALS OF ECU

1. CHECK DRIVER DOOR ECU



- (a) Disconnect the F23*1/F24*2 and D25 ECU connectors
(b) Measure the voltage and resistance of each terminal of the wire harness side connectors.

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|--|-------------------|-------------------------------|--|--------------------------------------|
| GND (D25-1) – Body ground | W-B – Body ground | Ground | Constant | Below 1 Ω |
| CPUB (D25-4) – Body ground | V-Y – Body ground | Battery (ECU power supply) | Constant | 10 to 14 V |
| SIG (D25-5) – Body ground | R-L – Body ground | Ignition power supply | Ignition switch 1: OFF → 2: ON | 1: 0 V → 2: 10 to 14 V |
| BDR (D25-6) – Body ground | R – Body ground | Battery (ECU power supply) | Constant | 10 to 14 V |
| A1+ (F23*1/F24*2-6) – A1- (F23-5) | L – W | Door closer power supply | Constant | 10 to 14 V |
| HALF (F23*1/F24*2-24) – KEYE (F23-21) | W-G – W-B | Half latch switch | 1: Driver door fully open → 2: Ajar | 1: Below 1 Ω → 2: 10 kΩ or higher |
| FULL (F23*1/F24*2-15) – KEYE (F23-21) | W-R – W-B | Full latch switch | 1: Driver door fully open → 2: Closed | 1: Below 1 Ω → 2: 10 kΩ or higher |

*1: LHD

*2: RHD


If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the F23*1/F24*2 and D25 ECU connectors.
(d) Measure the voltage of each terminal of the connector.

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|--------------------------------------|--------------|--------------------------|---|---|
| A1+ (F23*1/F24*2-6) – GND (D25-1) | L – W-B | Door closer power supply | 1: Driver door open → 2: Ajar → 3: Motor clockwise rotation → 4: Rotation complete | 1: 0 V → 2: 0 V → 3: 10 to 14 V → 4: 0 V |
| A1- (F23*1/F24*2-5) – GND (D25-1) | W – W-B | Door closer power supply | 1: Driver door closed → 2: Open (motor counterclockwise rotation) → 3: Operation complete | 1: 0 V → 2: 10 to 14 V → 3: 0 V |

If the result is not as specified, the driver door ECU may be a malfunction.

2. CHECK PASSENGER DOOR ECU



- (a) Disconnect the F17 and F24*1/F23*2 ECU connectors.
 (b) Measure the voltage and resistance of each terminal of the wire harness side connectors.

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|--|-------------------|-------------------------------|---|--------------------------------------|
| GND (F17-1) – Body ground | W-B – Body ground | Ground | Constant | Below 1 Ω |
| CPUB (F17-4) – Body ground | V-Y – Body ground | Battery (ECU power supply) | Constant | 10 to 14 V |
| SIG (F17-5) – Body ground | R-L – Body ground | Ignition power supply | Ignition switch 1: OFF → 2: ON | 1: 0 V → 2: 10 to 14 V |
| BDR (F17-6) – Body ground | R – Body ground | Battery (ECU power supply) | Constant | 10 to 14 V |
| A1+ (F24*1/F23*2-6) – A1- (F24-5) | L – W | Door closer power supply | Constant | 10 to 14 V |
| HALF (F24*1/F23*2-24) – KEYE (F24-21) | W-G – W-B | Half latch switch | 1: Passenger door fully open → 2: Ajar | 1: Below 1 Ω → 2: 10 kΩ or higher |
| FULL (F24*1/F23*2-15) – KEYE (F24-21) | W-R – W-B | Full latch switch | 1: Passenger door fully open → 2: Closed | 1: Below 1 Ω → 2: 10 kΩ or higher |


If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the F17 and F24*1/F23*2 ECU connectors.
 (d) Measure the voltage of each terminal of the connector.

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|--------------------------------------|--------------|--------------------------|--|---|
| A1+ (F24*1/F23*2-6) – GND (F17-1) | L – W-B | Door closer power supply | 1: Passenger door open → 2: Ajar → 3: Motor clockwise rotation → 4: Rotation complete | 1: 0 V → 2: 0 V → 3: 10 to 14 V → 4: 0 V |
| A1- (F24*1/F23*2-5) – GND (F17-1) | W – W-B | Door closer power supply | 1: Passenger door closed → 2: Open (motor counterclockwise rotation) → 3: Operation complete | 1: 0 V → 2: 10 to 14 V → 3: 0 V |

If the result is not as specified, the passenger door ECU may be a malfunction.

3. CHECK REAR DOOR ECU LH



P

B75330

- (a) Disconnect the R15 and R35 ECU connectors.
 (b) Measure the voltage and resistance of each of the wire harness side connectors.

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|----------------------------------|-------------------|-------------------------------|---|---|
| GND (R15-6) – Body ground | W-B – Body ground | Ground | Constant | Below 1 Ω |
| CPUB (R15-1) – Body ground | V-Y – Body ground | Battery (ECU power supply) | Constant | 10 to 14 V |
| SIG (R15-26) – Body ground | R-L – Body ground | Ignition power supply | Ignition switch 1: OFF → 2: ON | 1: 0 V → 2: 10 to 14 V |
| BDR (R15-2) – Body ground | R – Body ground | Battery (ECU power supply) | Constant | 10 to 14 V |
| A1+ (R35-6) – A1- (R36-5) | L – W | Door closer power supply | Constant | 10 to 14 V |
| HALF (R35-24) – DLE1 (R36-21) | W-G – W-B | Half latch switch | 1: Passenger door fully open → 2: Ajar | 1: Below 1 Ω → 2: 10 k Ω or higher |
| FULL (R35-15) – DLE1 (R36-21) | W-R – W-B | Full latch switch | 1: Passenger door fully open → 2: Closed | 1: Below 1 Ω → 2: 10 k Ω or higher |


If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the R15 and R35 ECU connectors.
 (d) Measure the voltage of each terminal of the connector.

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|------------------------------|--------------|--------------------------|---|---|
| A1+ (R35-6) – GND (R15-6) | L – W-B | Door closer power supply | 1: Rear LH door open → 2: Ajar → 3: Motor clockwise rotation → 4: Rotation complete | 1: 0 V → 2: 0 V → 3: 10 to 14 V → 4: 0 V |
| A1- (R35-5) – GND (R15-6) | W – W-B | Door closer power supply | 1: Rear LH door closed → 2: Open (motor counterclock- wise rotation) → 3: Operation complete | 1: 0 V → 2: 10 to 14 V → 3: 0 V |

If the result is not as specified, the rear door ECU LH may be a malfunction.

4. CHECK REAR DOOR ECU RH



P

B75330

- (a) Disconnect the R16 and R36 ECU connectors.
 (b) Measure the voltage and resistance of each of the wire harness side connectors.

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|----------------------------------|-------------------|-------------------------------|---|---|
| GND (R16-6) – Body ground | W-B – Body ground | Ground | Constant | Below 1 Ω |
| CPUB (R16-1) – Body ground | V-Y – Body ground | Battery (ECU power supply) | Constant | 10 to 14 V |
| SIG (R16-26) – Body ground | R-L – Body ground | Ignition power supply | Ignition switch 1: OFF → 2: ON | 1: 0 V → 2: 10 to 14 V |
| BDR (R16-2) – Body ground | R – Body ground | Battery (ECU power supply) | Constant | 10 to 14 V |
| A1+ (R36-6) – A1- (R37-5) | L – W | Door closer power supply | Constant | 10 to 14 V |
| HALF (R36-24) – DLE1 (R37-21) | W-G – W-B | Half latch switch | 1: Passenger door fully open → 2: Ajar | 1: Below 1 Ω → 2: 10 k Ω or higher |
| FULL (R36-15) – DLE1 (R37-21) | W-R – W-B | Full latch switch | 1: Passenger door fully open → 2: Closed | 1: Below 1 Ω → 2: 10 k Ω or higher |

If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the R16 and R36 ECU connectors.
 (d) Measure the voltage of each terminal of the connector.

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|------------------------------|--------------|--------------------------|---|---|
| A1+ (R36-6) – GND (R16-6) | L – W-B | Door closer power supply | 1: Rear RH door open → 2: Ajar → 3: Motor clockwise rotation → 4: Rotation complete | 1: 0 V → 2: 0 V → 3: 10 to 14 V → 4: 0 V |
| A1- (R36-5) – GND (R16-6) | W – W-B | Door closer power supply | 1: Rear RH door closed → 2: Open (motor counterclock- wise rotation) → 3: Operation complete | 1: 0 V → 2: 10 to 14 V → 3: 0 V |

If the result is not as specified, the rear door ECU RH may be a malfunction.