



INSPECTION

INSPECT BALL JOINT FOR ROTATION CONDITION

- Flip the ball joint stud back and 4–5 times before installing the nut.
- Using a torque wrench, turn the nut continuously one turn every 3–5 seconds and take the torque reading on the 5th turn.

Torque (turning):

0.5 – 3.5 N·m (5 – 36 kgf·cm, 4.5 – 31 in·lbf)