


CIRCUIT DESCRIPTION

WIRING DIAGRAM



INSPECTION PROCEDURE


1 INSPECT FUSE (ABS-IG FUSE)



- (a) Remove the ABS-IG Fuse from the driver side J/B.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
ABS-IG Fuse	Below 1 Ω (Continuity)



NG

INSPECT FOR SHORT CIRCUIT IN ALL HARNESS AND COMPONENTS CONNECTED TO ECU-IG FUSE

OK

2 INSPECT BATTERY

- (a) Check the battery voltage.
- Standard:
Voltage: 10 to 14 V

NG

INSPECT CHARGING SYSTEM
(SEE PAGE 19-23)

OK

3 INSPECT SKID CONTROL ECU TERMINAL VOLTAGE (IG1 TERMINAL)

- (a) Connect the intelligent tester to the DLC3.
 (b) Start the engine.
 (c) Select the DATA LIST mode on the intelligent tester.

Item	Measurement Item Range (Display)	Normal Condition
ECU IG Power Voltage	ECU power supply voltage/ UNDER NORMAL OVER	OVER: 4 V or over NORMAL: 9.5 V to 4 V UNDER: Below 9.5 V

- (d) Read the voltage condition output from the ECU displayed on the intelligent tester.

OK:

"Normal" is displayed.

NG

Go to step 4


OK

REPLACE ABS & TRACTION ACTUATOR ASSY (SEE PAGE 32-53)**NOTICE:**

When replacing the ABS & TRACTION actuator assy, perform zero point calibration (see page 05-387).

4 INSPECT SKID CONTROL ECU CONNECTOR (GND TERMINAL CONTINUITY)

Skid Control ECU
 (harness side connector) (S48)



GND

T

G24767

- (a) Disconnect the skid control ECU connector.
 (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
S48-32 (GND) - Body ground	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR (GND TERMINAL - BODY GROUND)

OK

CHECK AND REPAIR HARNESS AND CONNECTOR (IG1 TERMINAL - BATTERY)