


INSPECTION




1. INSPECT FUEL LID OPENER SWITCH

- (a) Remove the switch.
- (b) Measure the resistance of the switch.

Standard:

Tester Connection	Switch Condition	Specified Condition
1 – 2	Not pulled	10 kΩ or higher
1 – 2	Pulled	Below 1 Ω

If the result is not as specified, replace the switch assy.



2. INSPECT FUEL LID OPENER MOTOR

- (a) Check operation of the motor.
 - (1) Apply battery voltage to the motor and check operation of the motor.

OK:

Measurement Condition	Specified Condition
Battery positive (+) → Terminal 2 Battery negative (–) → Terminal 1	Moves to open direction

If the result is not as specified, replace the door lock assy.

- (b) Check the shaft strokes.

Standard: 10.6 mm (0.417 in.) or more