

STEERING LOCK SYSTEM

05ISW-01

PRECAUTION

NOTICE:

When the negative (–) battery terminal is disconnected, initialize the following systems after the terminal is reconnected.

System Name	See page
Power Window Control System	01-20
Front Power Seat Control System	01-20
Back Guide Monitor System	01-20