

DATA LIST/ACTIVE TEST

1. DATA LIST

HINT:

Using the intelligent tester II DATA LIST allows switch, sensor, actuator and other item values to be read without removing any parts. Reading the DATA LIST early in troubleshooting is one way to shorten labor time.

- (a) Connect the intelligent tester II to the DLC3.
- (b) Turn the ignition switch ON.
- (c) Read the DATA LIST according to the display on the tester.

Driver side J/B ECU:

Item	Measurement Item/Display (Range)	Normal Condition	Diagnostic Note
Fuel Lid Opn SW	Fuel lid opener switch signal /ON or OFF	ON: Fuel lid opener switch is pushed OFF: Fuel lid opener switch is not pushed	–

2. ACTIVE TEST

HINT:

Performing the intelligent tester II ACTIVE TEST allows relay, VSV, actuator and other items to be operated without removing any parts. Performing the ACTIVE TEST early in troubleshooting is one way to shorten the labor time. The DATA LIST can be displayed during the ACTIVE TEST.

- (a) Connect the intelligent tester II to the DLC3.
- (b) Turn the ignition switch ON.
- (c) Perform the ACTIVE TEST according to the display on the tester.

Luggage room J/B ECU:

Item	Test Details	Diagnostic Note
Fuel Lid Open	Operate fuel lid opener motor OFF/ON	–