

|            |              |  |
|------------|--------------|--|
| <b>DTC</b> | <b>P0985</b> | <b>SHIFT SOLENOID "E" CONTROL CIRCUIT LOW (SHIFT SOLENOID VALVE SR)</b>  |
| <b>DTC</b> | <b>P0986</b> | <b>SHIFT SOLENOID "E" CONTROL CIRCUIT HIGH (SHIFT SOLENOID VALVE SR)</b> |

## CIRCUIT DESCRIPTION

Shifting from 1st to 6th is performed in combination with "ON" and "OFF" operation of the shift solenoid valves SL1, SL2, S1, S2, S3, S4 and SR which is controlled by the ECM. If an open or short circuit occurs in either of the shift solenoid valves, the ECM controls the remaining normal shift solenoid valve to allow the vehicle to be operated smoothly. (In case of an open or short circuit, the ECM stops sending current to the circuit.) Fail-safe function (see page 05-553).


| DTC No. | DTC Detection Condition   | Trouble Area   |
|---------|---|--|
| P0985   | ECM detects short in solenoid valve SR circuit 2 times when solenoid valve SR is operated (1-trip detection logic)    | <ul style="list-style-type: none"> <li>• Short in shift solenoid valve SR circuit</li> <li>• Shift solenoid valve SR</li> <li>• ECM</li> </ul> |
| P0986   | ECM detects open in solenoid valve SR circuit 2 times when solenoid valve SR is not operated (1-trip detection logic) | <ul style="list-style-type: none"> <li>• Open in shift solenoid valve SR circuit</li> <li>• Shift solenoid valve SR</li> <li>• ECM</li> </ul>  |

## MONITOR DESCRIPTION

These DTCs indicate an open or short in the shift solenoid valve SR circuit. When there is an open or short circuit in any shift solenoid valve circuit, the ECM detects the problem and illuminates the MIL and stores the DTC. When the shift solenoid valve SR is on, if resistance is 3 Ω or less, the ECM determines there is a short in the shift solenoid valve SR circuit.


When the shift solenoid valve SR is off, if resistance is 100 kΩ or more, the ECM determines there is an open in the shift solenoid valve SR circuit (see page 05-553).

## WIRING DIAGRAM



# INSPECTION PROCEDURE

## 1 INSPECT TRANSMISSION WIRE (SR)



- Disconnect the transmission wire connector from the transaxle.
- Measure the resistance according to the value(s) in the table below.

### Standard:


| Tester Connection | Specified Condition<br>20°C (68°F) |
|-------------------|------------------------------------|
| 6 - Body Ground   | 11 to 5Ω                           |

NG

Go to step 3

OK

## 2 CHECK HARNESS AND CONNECTOR (TRANSMISSION WIRE - ECM)



- Connect the transmission connector to the transaxle.
- Disconnect the connector from the ECM.
- Measure the resistance according to the value(s) in the table below.

### Standard:

| Tester Connection         | Specified Condition<br>20°C (68°F) |
|---------------------------|------------------------------------|
| E7 - 2 (SR) - Body Ground | 11 to 5Ω                           |


NG

REPAIR OR REPLACE HARNESS OR CONNECTOR (SEE PAGE 10-44)

OK

REPLACE ECM (SEE PAGE 10-21)

3 INSPECT SHIFT SOLENOID VALVE (SR)



- (a) Remove the shift solenoid valve SR.
  - (b) Measure the resistance according to the value(s) in the table below.
- Standard:**

| Tester Connection                            | Specified Condition<br>20°C (68°F) |
|--|------------------------------------|
| Solenoid Connector (SR) – Solenoid Body (SR) | 11 to 15 Ω                         |

- (c) Connect positive (+) lead to the terminal of solenoid connector, negative (–) lead to the solenoid body.
- OK:**  
The solenoid makes an operating noise.

NG ➞ REPLACE SHIFT SOLENOID VALVE (SR)

OK

REPAIR OR REPLACE TRANSMISSION WIRE (SEE PAGE 40-28)