

INSPECTION

1. CHECK EVAPORATOR AND HEATER RADIATOR FINS FOR FOREIGN MATTER

If foreign matter is attached to the fin, blow it off with compressed air.

NOTICE:

Never use water to clean the evaporator.

2. CHECK FITTINGS FOR CRACKS OR SCRATCHES

(a) Repair as necessary.

3. INSPECT EVAPORATOR TEMPERATURE SENSOR CIRCUIT (SEE PAGE 05-807)

4. INSPECT COOL AIR BYPASS DAMPER POSITION SENSOR CIRCUIT (DRIVER SIDE) (SEE PAGE 05-853)

5. INSPECT COOL AIR BYPASS DAMPER CONTROL SERVOMOTOR CIRCUIT (DRIVER SIDE) (SEE PAGE 05-874)

6. INSPECT COOL AIR BYPASS DAMPER POSITION SENSOR CIRCUIT (PASSENGER SIDE) (SEE PAGE 05-858)

7. INSPECT COOL AIR BYPASS DAMPER CONTROL SERVOMOTOR CIRCUIT (PASSENGER SIDE) (SEE PAGE 05-878)

8. INSPECT WATER VALVE CONTROL SERVOMOTOR CIRCUIT (SEE PAGE 05-882)

9. INSPECT AIR VENT MODE DAMPER CONTROL SERVOMOTOR CIRCUIT (SEE PAGE 05-886)

10. INSPECT AIR MIX DAMPER CONTROL SERVOMOTOR CIRCUIT (SEE PAGE 05-891)