

SUSPENSION CONTROL ECU COMMUNICATION STOP MODE


MODE DESCRIPTION


Detection Item	Symptom	Trouble Area
SUSPENSION CONTROL ECU COMMUNICATION STOP MODE	<ul style="list-style-type: none">• "Air Suspension" is not displayed on the "Communication Bus Check" screen of the intelligent tester II.• Applies to "SUSPENSION CONTROL ECU COMMUNICATION STOP MODE" in the "DTC COMBINATION TABLE" [see page 05-3309].	<ul style="list-style-type: none">• Power source or inside the suspension control ECU• Suspension control ECU sub bus line or connector

NOTICE:

This is not applicable to a vehicle without an air suspension system.


WIRING DIAGRAM





INSPECTION PROCEDURE

1 CHECK CAN BUS LINE FOR DISCONNECTION (SUSPENSION CONTROL ECU SUB BUS LINE)

Suspension Control ECU
Wire Harness View:

- Turn the Ignition Switch to the LOCK position.
- Disconnect the Suspension Control ECU connector (A24).
- Measure the resistance according to the value(s) in the table below.

Standard:


Tester Connection	Condition	Specified Value
A24-7 (CANH) – A24-8 (CANL)	Ignition Switch OFF	54 to 69 Ω

NG

REPAIR OR REPLACE SUSPENSION CONTROL ECU SUB BUS LINE OR CONNECTOR (CAN-H, CAN-L)

OK

2 CHECK WIRE HARNESS (B, GND)

Suspension Control ECU
Wire Harness View:

- Measure the resistance according to the value(s) in the table below.
- Measure the voltage according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Value
A24-4 (GND) – Body Ground	Always	Below 1 Ω
A24-1 (B) – Body Ground	Ignition Switch ON	10 to 14 V

NG

REPAIR OR REPLACE WIRE HARNESS OR CONNECTOR

OK

REPLACE SUSPENSION CONTROL ECU (SEE PAGE 25-20)