

CUSTOMIZE PARAMETERS

HINT:

The following items can be customized.

NOTICE:

- When the customer requests a change in a function, first make sure that customization of the function(s) is possible.
- Be sure to record the current settings before customizing.
- When troubleshooting a function, first make sure that the function is not set to OFF.

Theft warning ECU:

Display (Item)	Default	Contents	Setting
Smart Ignition (Smart ignition)	Fr & Rr	Function that sets available areas for smart key to start engine and cancel steering lock.	Front/Fr & Rr
Transmit Intval (Transmission interval)	300 ms	Function that sets smart key signal interval transmitted from outside of vehicle when vehicle is parked.	150ms/300ms/ 450ms/600ms
Smart Trunk (Smart trunk)	ON	Function that opens trunk with smart key.	ON/OFF
Smart Trnk-K In (Smart trunk key inside)	ON	Function that opens trunk automatically when trunk is closed with smart key left inside. If owner forgets that trunk is opened automatically by this function, it is possible vehicle may be stolen.	ON/OFF
P/W Control (P/W control)	ON	Function that closes window by pressing trigger switch for more than 3 seconds.	ON/OFF
Dor Op-CI Buz/P (Door open-close buzzer/p)	ON	Function that makes warning available when smart key is taken outside vehicle, any door is opened and closed, shift position is P and ignition switch is pushed or in ACC or ON position.	ON/OFF
Half Lock Buz (Half lock buzzer)	ON	Function that makes warning available when locking doors with smart key when doors are opened.	ON/OFF
Key Battery Buz (Key battery buzzer)	ON	Function that makes warning available when smart key cannot be identified.	ON/OFF
Key No Fit Buz (Key no fit buzzer)	ON	Function that makes warning available when smart key cannot be identified.	ON/OFF
Smart Buz Num (Smart buzzer number)	3 TIMES	Function that sets number of times that wireless buzzer sounds, which warns that ignition switch is still on.	10 TIMES/ 7 TIMES/ 5 TIMES/ 3 TIMES/ 0
Smart Buz Vol (Smart buzzer volume)	MAX	Function that sets sound volume of wireless buzzer, which warns that ignition switch is still on.	MAX/MID 3/MID 2/MID 1/MIN/OFF

Meter ECU:

DISPLAY (ITEM)	DEFAULT	CONTENTS	SETTING
Key Remind Volum (Key reminder buzzer volume)	LARGE	Function that changes volume of key reminder buzzer.	LARGE/MEDIUM
Key Remind Sound (Key reminder buzzer sound)	NORMAL	Function that changes frequency of key reminder buzzer.	NORMAL/FAST/SLOW/0 s