

## HOW TO PROCEED WITH TROUBLESHOOTING

The intelligent tester II can be used at step 3, 6, 9, 12.

### 1 Vehicle Brought to Workshop




### 2 Customer Problem Analysis (SEE PAGE 05-383)




### 3 Check and Clear DTCs (SEE PAGE 05-400)



### 4 Problem Symptom Confirmation



Symptom does not occur: Go to step 5




Symptom occurs: Go to step 6


### 5 Symptom Simulation (SEE PAGE 01-44)



### 6 DTC Check (SEE PAGE 05-400)




There is no output: Go to step 7



There is output: Go to step 8

### 7 Problem Symptoms Table (SEE PAGE 05-395)



Check for fluid leakage and Go to step 10

### 8 DTC Chart (SEE PAGE 05-409)



### 9 Circuit Inspection (SEE PAGE 05-412 to 05-512)



### 10 Identification of Problem



11	Repair
----	--------

12	Confirmation Test
----	-------------------

End
-----