


REAR DOOR RH ECU POWER SOURCE CIRCUIT


CIRCUIT DESCRIPTION

This circuit supplies power to operate the rear right door ECU.

WIRING DIAGRAM



RHD models



INSPECTION PROCEDURE

1 CHECK FUSE (RR DOOR RH, MPX-B1, MPX-IG, AM1)


- (a) Remove the RR DOOR RH and MPX-B1 fuses from the passenger side J/B.
- (b) Remove the MPX-IG and AM1 fuses from the driver side J/B.
- (c) Measure the resistance.

Standard: Below 1 Ω

NG → REPLACE FUSE

OK

2 INSPECT RELAY (D-IG1)



- (a) Remove the D-IG1 relay from the driver side J/B.
- (b) Check the resistance.


Standard:

Tester Connection	Specified Condition
3 - 5	10 kΩ or higher
3 - 5	Below 1 Ω (when battery voltage is applied to terminals 1 and 2)

NG → REPLACE RELAY

OK

3 CHECK WIRE HARNESS (REAR DOOR RH ECU - BODY GROUND)



- (a) Disconnect the R16 ECU connector.
- (b) Measure the voltage and resistance between the wire harness side connector and body ground.

Standard:

Tester Connection	Condition	Specified Condition
R16-1 (CPUB) - Body ground	Constant	10 to 14 V
R16-2 (BDR) - Body ground	Constant	10 to 14 V
R16-6 (GND) - Body ground	Constant	Below 1 Ω
R16-26 (SIG) - Body ground	Ignition switch ON	19 to 14 V

NG → REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE
(See page 05-2529)