

CUSTOMIZE PARAMETERS

HINT:

The followings are the possible items to be customized.

NOTICE:

- After confirming whether the items of the customer's request is applicable or not for the customized items, perform the customize operation.
- Be sure to record the current value before customizing.
- When troubleshooting, be aware that function may be set to OFF by customizing. (Example: In the case of "The wireless operation does not function", check that wireless operation is not set to OFF by customizing, then perform the troubleshooting.)

AIR CONDITIONER

DISPLAY (ITEM)	DEFAULT	CONTENTS	SETTING
SET TEMP SHIFT (Set Temperature Shift)	NORMAL	To control with the shifted temperature against the display temperature.	+2C / +1C / NORMAL -1C / -2C
AIR INLET MODE (Air Inlet Mode)	AUTO	In case of turning the A/C ON when you desire to make the compartment cool down quickly, this is the function to change the mode automatically to RECIRCULATED mode.	MANUAL / AUTO
COMPRESSOR MODE (Compressor Mode)	AUTO	Function to turn the A/C ON automatically by pressing the AUTO button when the blower is ON and the A/C is OFF.	MANUAL / AUTO
COMPRS/DEF OPER (Compressor/Air Inlet DEF Operation)	LINK	Function to turn the A/C ON automatically linking with the FRONT DEF button when A/C is OFF.	NORMAL / LINK
MOTOR INITIALIZ (Step Motor Initializing (IG/off))	OFF	Function to initialize the step motor after the ignition switch is OFF.	ON / OFF
EVAP CTRL (External Variable Control OFF)	AUTO	Function to set the evaporator control to the AUTOMATIC position (AUTO) to save power or to the coldest position (MANUAL) to dehumidify the air and to prevent the windows from fogging up.	MANUAL / AUTO
GAS SENS SHIFT (Shift Emission Gas Sensor Sensitivity)	NORMAL	Function to change the sensitivity of the exhaust gas sensor.	MU MORE / MORE / LI MORE / NORMAL / LI LESS / LESS / MU LESS
AUTO MODE (Cancel Auto Mode)	AUTO	Function to swing the vent vans automatically when A/C is ON.	MANUAL / AUTO
BUTTON PRS BUS (Cancel Operating Switch Sound)	ON	Function to sound a buzzer when a button is pressed.	OFF / ON
FILTER SENS (Shift Filter Clog Sensitivity)	NORMAL	Function to change the sensitivity of the air conditioning filter choking sensor.	LESS / NORMAL / MORE
FOOT AIR LEAK (Cancel Air Outlet Foot II)	ON	Function to cut off the airstream felt underfoot while the vehicle is moving.	OFF / ON