

DTC**B2006****LEFT SIDE MOTOR LINE MALFUNCTION LO**

CIRCUIT DESCRIPTION

The seat belt control ECU receives information from the cruise control ECU (distance control ECU) through CAN communication and then tightens the seat belt by operating the motor in the front seat outer belt LH.

NOTICE:

The pretensioner is built into the front seat outer belt LH. Be sure to follow the correct inspection procedure, as failure to follow the correct procedure (such as inspection of incorrect connectors) may activate the pretensioner.

DTC No.	DTC Detection Condition	Trouble Area
B2006	<ul style="list-style-type: none">• Short to ground in seat belt motor LH circuit continues for 1 second or more• Short in seat belt motor LH circuit	<ul style="list-style-type: none">• Front seat outer belt assy LH• Wire harness (Seat belt control ECU – Front seat outer belt assy LH)• Seat belt control ECU

WIRING DIAGRAM

See page 05-109.


INSPECTION PROCEDURE

1 CHECK WIRE HARNESS (FRONT SEAT OUTER BELT ASSY LH – SEAT BELT CONTROL ECU)

Wire Harness Side

S66

Front Seat Outer Belt Assy LH



H45168

- (a) Turn the ignition switch OFF.
- (b) Disconnect the cable from the negative (–) battery terminal.
- (c) Disconnect the S65 ECU connector.
- (d) Disconnect the S66 belt connector.
- (e) Measure the resistance of the wire harness side connector.

Standard:


Tester Connection	Specified Condition
S66-1 – Body ground	10 kΩ or higher
S66-2 – Body ground	10 kΩ or higher
S66-1 – S66-2	10 kΩ or higher

NG


REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

2 CHECK FRONT SEAT OUTER BELT ASSY LH



S66

Front Seat Outer
Belt Assy LH

H

G25196

- (a) Measure the resistance of the seat belt connector.

Standard:

Tester Connection	Specified Condition
S66-1 – Body ground	10 kΩ or higher
S66-2 – Body ground	10 kΩ or higher

NG

**REPLACE FRONT SEAT OUTER BELT ASSY LH
(See Pub. No. RM1049E, page 61-17)**

OK

REPLACE SEAT BELT CONTROL ECU (See page 61-1)