


REPLACEMENT

1. DISCONNECT BATTERY NEGATIVE TERMINAL
2. DRAIN ENGINE COOLANT (See page 6-8)
3. REMOVE ENGINE UNDER COVER NO.1
4. REMOVE RADIATOR ASSY (See page 6-20)
5. REMOVE TIMING BELT (See page 4-71)




6. REMOVE WATER INLET HOUSING

- (a) Disconnect the water hose and remove the 2 bolts, inlet housing and O-ring.

7. REMOVE TIMING BELT IDLER SUB-ASSY NO.2 (See page 4-42)

8. REMOVE WATER PUMP ASSY

- (a) Remove the 5 bolts, water pump and gasket.



9. INSTALL WATER PUMP ASSY

- (a) Install a new gasket and the water pump with the 5 bolts, 2 stud bolts and nut.

Torque:

21 N·m (215 kgf·cm, 15 ft·lbf) for bolt


18 N·m (185 kgf·cm, 13 ft·lbf) for stud bolt

HINT:

Use a bolt this is 30 mm (1.18 in.) in length.

NOTICE:

Uniformly tighten the bolts, stand bolts and nuts. Tighten them little by little in diagonal pairs. For example, after tightening an upper-right side bolt 30%, tighten a lower-left side bolt 30%; or after tightening a left side bolt 30%, tighten a right side bolt 30%.



10. INSTALL WATER INLET HOUSING


- (a) Install a new O-ring.
- (b) Apply soapy water to the O-ring.
- (c) Apply seal packing to the groove of the water inlet housing as shown in the illustration.

Seal packing: Part No. 08826-00100 or equivalent

NOTICE:

- After applying seal packing, install the part within 5 minutes.

- **Be sure to keep this O-ring away from engine oil. The O-ring must be replaced if it contacts engine oil.**



- (d) Install the water inlet housing with the 2 bolts, then connect the water hose.

Bolt length:

75 mm (2.95 in.) for bolt A

25 mm (0.98 in.) for bolt B

11. INSTALL TIMING BELT IDLER SUB-ASSY NO.2 (See page 4-42)
12. INSTALL TIMING BELT (See page 4-71)
13. INSTALL RADIATOR ASSY (See page 6-20)
14. REFILL ENGINE COOLANT (See page 6-8)
15. CONNECT BATTERY NEGATIVE TERMINAL
16. POWER WINDOW CONTROL SYSTEM INITIALIZE (See page 01-20)
17. FRONT POWER SEAT CONTROL SYSTEM INITIALIZE (See page 01-20)
18. BACK GUIDE MONITOR SYSTEM INITIALIZE (See page 01-20)
19. CHECK FOR ENGINE COOLANT LEAKS (See page 6-1)
20. INSTALL ENGINE UNDER COVER NO.1